

Franklin®

CUSTOMER SERVICE COMMITMENT

Thank you for purchasing this Franklin® product! In the event that the product you've purchased has missing or damaged parts, please contact us at:

parts@franklinsports.com

or

Visit our website at: www.franklinsports.com/52859

If possible, please include product part number and parts description so we can best assist you.

WE'RE HERE FOR YOU!

PLEASE DO NOT RETURN THIS PRODUCT TO THE STORE IT WAS PURCHASED FROM.

WE ARE COMMITTED TO FULFILLING ALL REPLACEMENT PART NEEDS IMMEDIATELY.










Thank you for your continued support, and welcome to the #FranklinFamily!

Franklin® ITEM#: **52859**

1

For replacement parts:
Visit: www.franklinsports.com/52859
Email: parts@franklinsports.com
Call: 1-800-225-8649

PARTS LIST

				QTY x1
Net Rep. Part: 52859-R1				
2	3	4	5	
				
QTY x2	QTY x1	QTY x1	QTY x2	
Pole with Male and Female End	Pole with Male and Female End	Pole with Double Male End	Frame End	
Rep. Part: 52859-R2	Rep. Part: 52859-R3	Rep. Part: 52859-R4	Rep. Part: 52859-R5	
6	7	8	9	
				
QTY x2	QTY x2	QTY x2	QTY x2	
Net Pole Bottom	Net Pole Top	Wooden Paddle	X-40 Outdoor Pickleball	
Rep. Part: 52859-R6	Rep. Part: 52859-R7	Rep. Part: 52859-R8	Rep. Part: 52859-R9	

ASSEMBLY INSTRUCTIONS

GENERAL NOTE

- Find a clean, level place to begin the assembly of your Pickleball Net. We recommend that two adults work together to assemble this Pickleball Net.
- Remove all the parts from the box and verify that you have all of the listed parts as shown on the parts list page.
- Remove the caps (as shown below) from the **Frame Ends (#5)** and dispose of them. These are only used to protect the product during shipment.




Figure 1

Franklin® ITEM#: **52859**


2

For replacement parts:
Visit: www.franklinsports.com/52859
Email: parts@franklinsports.com
Call: 1-800-225-8649

STEP 1




PARTS



NOTE

Connect all of the Poles with Male and Female End (#2 & #3) and Pole with Double Male End (#4) together.

STEP 2




PARTS




NOTE

Attach the Frame End (#5) to each end so that the ends of part 5 are facing toward the ground.

STEP 3




PARTS




NOTE

Insert the Net Pole Top (#7) and Net Pole Bottom (#6) into the middle section on the Frame End (#5).

STEP 4




PARTS



NOTE

To install the Net (#1), orient the net so the adjustment strap is on the top and slide on one side of the net only 6in (15.2cm). Go to the second pole and slide that one down about 6in (15.2cm). Continue to install the net by sliding each end on about 6in (15.2cm) at a time in an alternating fashion.

STEP 5



PARTS



NOTE

Once the Net (#1) is fully installed, use the self-stick straps at the top of the net to adjust the tension of the top of the net.